


DataSheet

Solimar External Mounting Assemblies

ProSpare


Solimar fluidisers are renowned for extremely effective performance in keeping powders flowing at optimum speed. One of the key Solimar advantages is that their fluidisers can be installed safely from outside the silo. Two different mounting assemblies are available for installing the market leading fluidiser in silos, hoppers and bins. Regular inspection and maintenance can be performed quickly and simply without the need to enter the vessel.



Fast-Fit

The fluidiser is inserted through an installation hole and held in place with a clever alignment plate and sealing washer. User friendly cable system.

- Minimal silo modification
- Provides tight seal with no material or air leaks
- Works with silos, bins and hoppers with a tight radius
- Use with flat or conical hoppers
- Stainless steel alignment plate



Easy-In

The Easy-In mounting plate is inserted through an oval or rectangular hole and held in place with a heavy duty locking bar. Ideal for easy inspection and maintenance.

- Stainless steel mounting plate provides clean surface for fluidiser to seal against
- Recommended for older vessels
- Integral gasket seals tight and compensates for slight imperfections with no leaks
- Options for flat sided and curved vessels



Sole Agent in
UK and Ireland



Insist on genuine Solimar disks with
the trademarked radial ridge design

ProSpare

Castlewood Business Park, Farmwell Lane, Sutton-in-Ashfield, Nottinghamshire. NG17 1BX.

Tel • +44 (0)1773 814008 • Fax • +44 (0)1773 860055 • Email • sales@prospare.co.uk

prospare.co.uk